

Atom 9 HPS

Laser Display Systems



| | |
|-----------------------------------|--|
| Type: | full colour semiconductor diode laser system |
| Guaranteed optical output: | 9W |
| Suitable for: | indoor/outdoor laser displays and high performance laser graphics |
| System control: | inbuilt Pangolin FB-MAX QS with network switch, Pangolin QuickShow 4.0 laser control and creation software is included [upgrade to Beyond is available] |
| Control signal: | ILDA, Ethernet, ArtNet and SD card |
| Scanning system: | Saturn 1 90kpps @ 7° |
| Safety: | fully complies with the latest EN 60825-1, FDA regulations and TUV Laser Safety |
| Weight: | 28kg |
| Includes: | heavy duty flight case, power lead, 25M ILDA signal cable, E-STOP remote with 25M cable, set of 4 safety keys, interlock connector, CD with PDF manual. |
| R G B [mW]: | 2750 1700 5500 |
| Beam size [mm]: | 3x3 |
| Beam divergence | <1mrad [full angle] |
| Modulation: | analog, up to 100kHz |
| Power requirements: | 100-230V/50Hz |
| Consumption: | max. 390VA |
| Operation temperature: | 10-35°C |
| Ingress protection rating: | IP54 |
| System features: | All the basic control settings such as X & Y sizes, scan-fail safety settings etc. are adjusted digitally using inbuilt interface. This systems also features scanning system protection and daisy chain of emergency STOP signal for multiple system "one-hit" operation. |
| Integrated laser safety features: | Keyed interlock, emission delay, magnetic interlock, scan-fail safety, V-RAD 506 mechanical shutter reaction time <20ms, adjustable aperture masking plate. |

We officially launched our first semiconductor diode laser system back in 2011 in Birmingham, UK. Today's Atom series combines modern semiconductor diode laser technology with battlefield proven design and FB4 controller. Our Atoms already showed their potential in power demanding applications whilst we manage to keep the purchase costs at a reasonable level.

KVANT Atom 9 HPS is a powerful semiconductor laser system designed mainly for graphic-heavy laser applications. This robust system is built to last and it is equipped with the 90kpps Saturn 1 scanning as standard.