

---

# Dichroic mirror, 50 x 50 mm (HR R, HT B+G)

Optical parts and Scanner sets



---

This dichroic mirror is used to reflect RED laser beam and to transmit BLUE and GREEN laser beam with efficiency more than 97%.

The available thickness is 1 and 2mm, please define the preferred thickness in you order. Generally the 2mm mirrors have better flatness at larger areas. Our 2mm thick mirrors have flatness  $\lambda/4$  at each 10x10mm area.

The glass can be cut easily by a diamond. Different size is available on request, please contact us directly.