

Coherent LaserCheck power meter

Laser Display Safety



Power measurement range:	10 μ W - 10mW [1W with built-in attenuator]
Wavelength range:	\pm 8% calibrated accuracy from 400-1064 nm

LaserCheck is a small, lightweight, self-contained and RoHS compliant power meter that can easily be stored in a pocket or tool kit.

The instrument is micro-processor controlled with wavelength correction, auto-ranging (μ W or mW displayed), power overload warning and automatic shutoff. At higher powers the embedded silicon photodiode is protected from saturation with a built-in optical attenuator.

It is very useful for taking some basic laser display safety measurements.